


SD Card Upgrade Instructions for PMP3170B

1. Copy the file needed to upgrade into SD card. Packed file name is **update.zip**.
2. Enter into the Recovery mode by following the instructions below

You have to power off your tablet. Then tablet would be powered off - press "Volume-" button, then press Power button, several seconds later, it will enter into upgrade picture (the picture is a Small robot with "!"). Then click "Volume-", enter into Recovery mode.



3. Start to upgrade system: click "Volume-" button to slide down, click the second selection "apply SD card : update.zip", click "Volume+" to enter into the interface for upgrade pack selection, select "update.zip" file, then click "Volume+" to start system upgrade

(Note: If there are many other files, you should make sure you have selected update file, then click "Volume+" to upgrade.)

4. Upgrade successfully: Device will indicates the upgrade finishes successfully.
5. Select the first selection "Reboot system now"; click "Volume+" button to confirm selection, then enter into system successfully.

Note:

1. Before upgrading, please make sure MID electric volume higher than 30%.
2. Please backup the important information, such as application, emails etc.
3. Since the model is different, Recovery mode has about 6 to 8 selections, and the selection quantity is decided by software.