


Introduction

Thank you for purchasing **Prestigio Solar Powered Bluetooth Hands Free**. You have made an excellent choice and we hope you will enjoy all of its capabilities. Please read through the quick guide carefully before using the product, and follow all of the procedures in the quick guide to fully enjoy all features of the product.



















Package Content

- Main Unit** X 1
Mounting Cradle Kit X 1
Car Charger X 1
- USB Cable** X 1
Quick Guide X 1
Warranty Card X 1

Product Overviews




Summary of Button Functions

Function	Device Status	Action
To power ON	Power OFF	Press and hold  for 2 seconds.
To power OFF	Power ON	Press and hold  for 5 seconds.
Turn volume UP/DOWN	Talking	Press  / 
Transferring a call	Talking	<ul style="list-style-type: none">● Press  once to transfer a call from the mobile phone to device.● Press and hold  for 1 second to transfer a call from device to mobile phone.
Answering a call	Ringing	Press 
Ending a call	Talking	Press 
Call waiting	Talking	Press and hold  for 1 second
Last number redialling	Idle	Press and hold  for 1 second
Voice dialing	Idle	Press 
To reject a call	Ringing	Press and hold  for 1 second
To start pairing	Power OFF	Press and hold  for 5 seconds
To turn ringing mute ON/OFF	Ringing	Press and hold  for 1 second
To turn MIC mute ON/OFF	Talking	Press and hold  for 1 second
Battery status	Power ON/Idle	Press  and  simultaneously
Solar power charging status ON/OFF	Power ON	Press and hold  for 5 seconds

LED Indicator Status and Signal Sound		
Function	Signal Sound	Status LED
Power ON	Booting tone	LED rapidly flashes in blue light 5 times
Power OFF	Shutdown tone	LED rapidly flashes in blue light 5 times
Pairing	Beeps twice	LED glows in blue light steadily
No connection between device & mobile phone Device & mobile phone are connected	No beep	LED flashes in blue light every 3 seconds
	Beeps once	LED flashes in blue light every 5 seconds
Unintentional loss of connetion	No beep	LED and battery status LED flash every 3 second
Mute function activated when a phone call is received	No beep	LED flashes in blue light every 0.5 seconds
Mute function activated during a phone call	Beeps periodically	LED flashes in blue light every 0.5 seconds
Charging using car charger	No beep	Battery status LED glows in red light
Charging completed	No beep	Battery status LED is off
Low battery power	Beeps periodically	LED flashes in blue light and battery status LED flashes in red light simulta-
		neously


Device Installation

Installing Device




To minimize obstruction to driver's view and to maximize MIC performance and solar charging power, it is recommended that the device be positioned and attached with either 3M tapes or suction cups on the top-left of the windshield as shown at the left.

Charging Device




By car charger:



- Open **PWR** charging port on device and connect car charger with device. Battery status LED should glow in red light.
- Device battery will be fully charged in approximately 2 hours.



By solar panel:

- Simply direct solar panel on the back of device towards sunlight.
- 3 hours of solar panel charging will provide approximately 30 minutes of talking time. Continuous charging will provide sufficient power to maintain regular operations.
- Press and hold  for 5 seconds to turn battery status LED ON/OFF. Please refer to previous section for more information.

Battery Status


● Press  and  simultaneously to display battery status.



Number of red flashes and beeps	4 times	3 times	2 times	once
Remaining talking time	> 7 hours	> 5 hours	> 3 hours	< 3 hours

● The status LED flashes in blue light and battery status LED flashes in red light simultaneously when device battery is lower than 10%.



Getting Started


Power ON/OFF




- Press and hold  for 2 seconds to turn device on. A booting tone is emitted and status LED flashes rapidly in blue light 5 times.
- Press and hold  for 5 seconds to turn device off. A shutdown tone is emitted and status LED flashes rapidly in blue light 5 times.

Pairing



- Begin with the device turned off. Press and hold  for 5 seconds. 2 short beeps will be emitted after booting tone and status LED will glow in blue light.
- Activate mobile phone bluetooth function and begin searching for bluetooth devices. Please refer to mobile phone manual for more information.
- Select "BHF2A" from the list of devices.
- Enter "0000" when prompted for a passkey.
- A beep will be emitted when the devices are paired up successfully.
- The device will exit pairing mode automatically without successful pairing.

Auto Reconnection

- The device will automatically reconnect to paired mobile phone in range after powering on.
- The device will also automatically reconnect to paired mobile phone previously out of range when devices are within range again. Press  to manually reconnect devices.


Basic Operations

Answering Calls




- Press to answer an incoming call.
- Press and hold for 1 second to activate ringing tone mute. Repeat the above procedure to resume ringing tone.
- Press and hold for 1 second to reject an incoming call.

Making/Ending Calls



- Press and speak the registered name on the voice dialing list to activate voice dialing function. This function is only available if supported by mobile phone.
- Press and hold for 1 second to activate last number redial function.
- Press to end a phone call.

During Phone Calls



- Press to adjust volume in 8 level.
- Press to transfer a phone call from mobile phone to device. Press and hold for 1 second to transfer a phone call from device to mobile phone.
- Press and hold for 1 second to activate MIC mute. A periodic beep is emitted during mute session. Repeat the above procedure to resume phone call.
- Press and hold for 1 second to receive 2nd incoming call (call waiting). Repeat the above procedure to resume 1st phone call.

Supplementary Information

Cautions

- Do **NOT** drop device from high grounds.
- Do **NOT** modify, repair, or take apart device.
- Do **NOT** expose device directly to water, alcohol, benzene solutions, etc. even for cleaning purpose.
- Do **NOT** expose device directly to heated or flammable sources.
- Do NOT place heavy objects on device.
- Protect device from humidity and dust.

Additional Informations

- The covering range of Bluetooth communication is designed to be within a maximum of 10 meters and actual conditions may vary according to surrounding environments and obstacles.
- The device is only compatible to those mobile phones supporting Bluetooth headset or hands free profile(s).
- To ensure proper operations, the device should not be in vicinity of other devices (wireless LAN devices, microwave oven, etc) operating in the same frequency range (ISM band, 2.402GHz ~ 2.480GHz).
- Please turn off the device in environment with potentially explosive atmosphere. In rare occurrences, the device could generate sparks which could lead to unexpected explosion and result in body injury.
- The rechargeable battery in device is designed to endure a long service life. A new battery or one that has not been used for a long period of time could experience reduced capacity the first few charging/discharging cycle.
- When device is being charged with solar panel, the operation time including talking time and standby time will be extended continuously without support from car charger.

Product Specifications	
Chipset	BC5MM
Bluetooth Version	2.1 Bluetooth Standard
Supported Profiles	HFP, HSP, SDAP, GAP
Frequency	2.402GHz ~ 2.480 GHz (ISM band)
Covering Range	10 Meter (33 Feet)
Speaker	32pi, 0.5W~0.8W
Operation Range	Up to 10 meter (33 feet)
Talking Time	15 Hours
Standby Time	500 Hours
MIC	4pi, 1.5T, -42dB
Battery Capacity	500mAh, 3.7V
Charging Time	2 Hours (car charger) 30 Hours (solar panel charger)
Product Dimensions	91.3mm (L) x 50.5mm (W) x 13.3mm (T)
Weight	60g

Technical Support and Warranty Information

Please refer to www.prestigio.com for technical support and included warranty card for warranty information.

Disclaimer

We make every effort to ensure that the information and procedures in this user manual are accurate and complete. No liability can and will be accepted for any erros or omissions. **Prestigio** reserves the right to make any changes without further notice to any products herein.