


Package Contents

- | | |
|----------------------|------------------|
| 1. Speaker Main Unit | 2. Audio Cable |
| 3. USB Cable | 4. User's Manual |
| 5. Warranty Card | |


Main Unit Overview



- | | |
|----------------------|--------------------|
| 1 Line-in Jack | 2 Mute Button |
| 3 Volume Down Button | 4 Volume Up Button |
| 5 Indicator | 6 USB Jack |


Basic Operations

● Connect to PC or Notebook



1. Connect the speaker to the PC or Notebook with the USB cable. The indicator glows in blue upon successful connection.
2. Press the **Volume up/ Volume down Button** to turn the volume up/down.
3. Press the **Mute Button** to disable the sound.

● Connect to Other Players



1. Connect the speaker to PC or Notebook with the USB cable for power supply. The indicator glows in blue upon successful connection.
2. Connect the player to the speaker with the included audio cable.
3. Press the **Volume up/ Volume down Button** to turn up/down the volume.
4. Press the **Mute Button** to disable the sound.

Technical Specifications

Power Supply	USB Power
S/N Ratio	>70 dB
Frequency	40 Hz- 20 KHz
Distortion	<1% 1W 1 KHz
Max Output	L2.5W+R2.5W RMS
Speaker Unit	1.5"4Ω3W × 2
Dimensions	204mm(L)×57mm(W)×45mm(H)
Weight	300g