

PMP7074B3G upgrade methods:

Step 1: Decompress the file and gain the upgrade file “upgrade.swan”; Copy the upgrade file upgrade.swan to the root directory of the T-Flash card

Step 2: Turn off the device. Insert the T-Flash card with the FW upgrade file in it.

Step 3: Press and hold the Volume button “+” on the upper of the device, and press and hold the Power button simultaneously. Release the Power button when the device vibrates. Release the Volume button when the upgrade progress screen appears.

Step 4: When the upgrade is done, the Upgrade successfully screen appears and prompt you to restart the device. Restart your device and the device upgrade succeed.

NOTE : System upgrade, the device customization options will revert to the default value, phone book, call history, SMS messages, loading of the APK, etc. will be deleted, to avoid loss of information, users have all required before upgrading to ensure that the data backup.