




1. Connect your eBook to the PC, backup all data on the eBook to the PC and process with update.
2. Unpack the archive with firmware and tool and launch executable file LiveSuit.exe in the "Tool and Driver folder".




3. Press "Yes" on the LiveSuit welcome screen window to launch the update master.




4. Select "General" upgrade mode.




5. Press “Yes” and choose the firmware image file from the unpacked archive.




6. Press “Connected” to confirm that your eBook is connected to the PC via USB.





7. Press “Yes” to confirm update.



8. Press “No” to enter normal upgrade mode.



9. Wait 5-6 minutes until the process is not complete. You will see a message windows "Update complete"



10. Wait 1 minute while eBook reboots, copy all your backup data back to eBook and disconnected it from the USB.