How to update?

1. Please open the page below:
http://www.navitel.su/en/

Install Navitel Navigator Updater

2. Connect the device to the computer. <mark>Make sure that the device is set to "Mass storage mode" before connect it.</mark>

3. Start Navitel Navigator Updater

4. Follow the steps below

Navitel Navigator update center

NAVITEL
v1.0.7.0

Settings

✅ **Following devices were found, choose the one to work with:**

Navitel Navigator 5.1.0.333 (G:)

Search device   Next   Exit

Navitel Navigator update center

NAVITEL
v1.0.7.0

Settings

✅ **Navitel Navigator executable was found. You may choose it for update:**

Navitel Navigator applications found:

Navitel Navigator 5.1.0.333

Description:

Can be updated to version 5.5.1.320
Version: 5.1.0.333
Path: G:\Navitel\Navitel.exe

or enter the path manually:

G:\Navitel\Navitel.exe   Select

Back   Next   Exit

5. Click twice on the star to show the option for map download:

6. Click on the Update button:

Navitel Navigator update center

Updating Navitel Navigator

▶ Preparing for download
▶ Checking files
▶ **Downloading file: NaviTel-5.5.1.320.PRESTIGIO_GV4050.zip**

Speed: 637 KB/s;   done: 2 from 22MB (11%);   time left: 32s

▶ Verifying files
▶ Creating backup
▶ Preparing for update installation
▶ Installing update

Cancel

Navitel Navigator update center

# Updating Navitel Navigator

▶ Preparing for download
▶ Checking files
▶ Downloading files
▶ Verifying files
▶ Creating backup
▶ Preparing for update installation
▶ **Installing update (don't unplug device untill operation is completed)**

Cancel

Navitel Navigator update center

NAVITEL
v1.0.7.0

Settings

Updating maps

▶ Preparing for download

▶ Checking files

▶ **Downloading file: bgr20120721.nm3**

Speed: 376 KB/s;   done: 24 from 82MB (29%);   time left: 2m 23s

▶ Verifying files

▶ Deleting old maps

▶ Installing update

Cancel

Navitel Navigator update center

NAVITEL
v1.0.7.0

Settings

Updating maps

▶ Preparing for download

▶ Checking files

▶ Downloading files

▶ Verifying files

▶ Deleting old maps

▶ **Installing file: bgr20120721.nm3**

Speed: 1,48 MB/s;   done: 11 from 82MB (13%);   time left: 48s

Cancel

After the update GPS received might be disconnected:

To switch it on, click on the GPS icon :

After the GPS received is connected the icon will change its colour:

Now your device is ready to navigate.